



SHREEJA™
**Health Care
Products**

PURE *House of Purity*

AN ISO 9001:2015 Certified Company

PURE OIL MAKER MACHINE

Make your Oil 100 % Pure

India's 1st

Home Made Oil Maker Machine

Website : www.shreejahealthcare.com

OIL MAKER MACHINE MANUAL CUM WARRANTY CARD



Customer Care No. :
7574000421, 7574000422

1 Year
Warranty*

Technical Parameters :

Capacity	: 2 - 5 Kg / hr (According to the material)
Voltage	: 210 - 230 V
Power	: 400 \pm 50 W
Weight	: 14 Kgs.
Material	: 304# food grade stainless steel
Machine dimension	: 460*240*190 mm
Packing Size	: 560*260*340 mm

Product Features :

1. Multi functional home oil maker machine for peanuts, Coconut, Sesame, Soybean, Almond, walnuts, sunflower seeds, vegetable seeds flaxseeds and so on....
2. The motor is industry motor that it can continue working for 8 to 10 hours. That will be good for the machine.
3. Oil extracting rate is up to 45 % which depends on the oil seed
4. Easy to operate, clean and move.
5. Working capacity (Just for reference):

Material	Efficiency
Peanut	2 - 3 kg / hr
Sesame	3 - 3.5 kg / hr
Sunflower	2.5 - 3 kg / hr
Walnut	3 - 3.5 kg / hr
Almond	2 - 3 kg / hr

Pressing Process (Press peanut for sample)



1. Turn on heating switch and wait for more than 10 minutes and extend the waiting time appropriately during the cold seasons (never turn it off in pressing oil process)
2. Directly put dry ingredients.
3. Press the “Squeezing” switch and start pressing oil.
4. After pressing ends. hold (don’t loosen) “Cleanup” switch for more than 20 seconds, and it will be easier to remove the screw and then clean; if you don’t press the cleanup switch when pressing chamber becomes cold, the interior residual slag harden and pressing rod will be blocked in the pressing chamber and cannot be taken out for cleaning.
5. In case of power outage during the process, please turn off the start switch and unplug power plug at the same time; continue to press after turning on the heating switch for more than 10 minutes when power is connected.

- Clean; remove pressing chamber and clean it with edible detergent and water.



- Pull out the power plug and store the machine in a dry place.
- The pressed oil will automatically separate after storing for a night under room temperature 15 degrees above and does not need to filter.

In the process, sometimes materials form aerial state in the feeding port because raw materials are damp, or the surface is not smooth, you can gently touch the raw materials.

Notice :

Never put fingers or hard objects such as metal bar into the entrance to the chamber to stir raw materials.

CLEANING PROCESS

1. First shut off the power and power plug, then pressing chamber remains heat; wear cotton heat-protective gloves so as to prevent burns, or wait for more than 30 minutes so as to let the pressing chamber cools down completely.
2. Take out the pressing rod and clean it with paper or cloth; rinse and clean the pressing chamber with water.
3. Never clean with acid, alkali, soda and salt water; the more raw material moisture content is, the tighter the raw material slag sticks to screws, more default it is to wash, and you can cut it off with knife; in addition to pressing chamber, other parts are forbidden to enter water or any other liquid; after cleaning, promptly wipe or blow the water on pressing chamber with hair dryer before storing.



HOW TO STORE THE OIL

After putting in room temperature above 15° C for one night, oil and thick liquid will separate automatically, and it does not need filtering; the longer it is placed, better separation effect is; after they are completely separated, bottle it and put into fridge or keep it at room.

DATE OF PURCHASE :
NAME OF PURCHASER :
BILL / INVOICE / CASH MEMON NO. :
DEALER'S STAMP & SIGNATURE
This warranty is not valid if above information is not duly filled in
We warrants this machine to be free from defects in materials and workmanship under normal use for a period of one(1) year from the date of purchase, as evidenced by the purchase receipt.
During the warranty period We shall repair the machine if defective. This warranty is limited to the purchaser and is not transferable.
*One year warranty only for electric motor.

SHREEJA HEALTH CARE PRODUCTS

Regd. Office : 26, Ground Floor, Ratnasagar Apartment,
Near Varachha Police Station, Surat - 395 006, Gujarat, India
Mob. : 99791 09757 Email : shreejahealthcare@gmail.com
Website : www.shreejahealthcare.com